
Chapter 6 Download

TABLE OF CONTENTS

Chapter 6 Download.....	1
6.1 General Information.....	2
6.1.1 Objectives.....	2
6.1.2 Legend.....	2
6.1.3 Reference Documentation	2
6.2 Communication to AC800M Controller.....	3
6.2.1 How to Configure the IP Address with AC 800PEC.....	3
6.2.2 How to Download the Firmware with AC 800PEC	4
6.2.3 How to Configure the IP Address in the CBM	5
6.3 Application Download.....	7
6.3.1 General.....	7
6.3.2 Restart Options	7
6.3.3 Download to Flash	8
6.3.4 Download to RAM only	8
6.3.5 Difference Report.....	10
6.4 Online Functions	11
6.4.1 General.....	11
6.4.2 Status of I/O-Signals	11
6.4.3 Forcing	12
6.5 Test Mode & SoftController.....	13
6.5.1 Test Mode.....	13
6.5.2 How to use the SoftController	13

6.1 General Information

6.1.1 Objectives

Upon completion of this chapter, you will be able to:

- Set up communication to controller AC 800M
- Download and test hardware in online mode

6.1.2 Legend

>	Indicates when you go from one menu to a sub-menu
<i>Italic</i>	Indicates object and file names
“ “	Indicates dialog box buttons, tabs, menus etc.
Bold	Indicates important topics
	Indicates start/explanation of student activity

6.1.3 Reference Documentation

3BSE036351	Industrial IT 800xA – Control and I/O AC 800M Controller - Hardware and Operation
3BSE041548	Industrial IT - Compact Control Builder AC 800M Getting Started – Introduction and Installation
3BSE040935	Industrial IT – Compact Control Builder AC 800M Basic Control Software – Introduction and Configuration


6.2 Communication to AC800M Controller

All controllers delivered from the factory have the same IP address. You must change the IP address to an address, which is available in your own network.

6.2.1 How to Configure the IP Address with AC 800PEC

A different procedure needs to be applied if an AC 800PEC controller is used. In order to manage the configuration of this controller (i.e. also configure the TCP/IP setting) a tool called PEC Configurator is used.

The PEC Configurator reads the configuration from the controller and displays it to the user. The user has the possibility to change the configuration of the controller and store the modified configurations back to the target.




Please, refer to the AC 800PEC PEC Configurator User Manual for a detailed description of this tool.


You might also use the PC Installer for changing the IP-Address

6.2.2 How to Download the Firmware with AC 800PEC

A tool called PEC Installer is used either to update the platform- and control software of an AC 800PEC controller and to backup the software from an AC 800PEC controller to the PC: in the PEC Installer, the first use case is called 'Download', the second one is called 'Upload'.




Do a backup (upload):



6.2.3 How to Configure the IP Address in the CBM

After setting the controller's IP address, you must do the IP address settings of the controller in CBM in two steps:


1. Right click the *Controller*, choose “Properties > System Identity” and then set the desired IP address of the controller.




The System Identity is the network address of the selected controller. The network address is shown beside the controller icon in the Project Explorer tree.

NOTE! The default address is 172.16.0.0

2. Open the controller's *PM8xx/TP830* and then double click the first Ethernet.



This will open a new window, click on the “Settings” tab, then set the same IP address and subnet mask as you have set with the *IPConfig* tool.



NOTE! The system identity should normally correspond to the setting for Ethernet 1 on the AC800M.

6.3 Application Download

6.3.1 General

During a download, the code that has been written is checked and compiled. The controller receives the compiled application and begins executing it immediately.

Once your application has been compiled, you can:

- **Download the application and go Online.**
This updates the application in the controller.
- **Go online without download of the application.**
Useful when, for example, monitoring values in the controller without disturbing the controller.

A version analysis of the applications is made when you download. The analysis results are used to determine if and how applications shall be updated to new versions in the controllers.

For the AC800PEC it is always recommended to load the application to the because of different save cold retain value handling

6.3.2 Restart Options

When the system restarts, variables with No Retain, Retain and Cold Retain attributes will behave differently. It will also matter if the system performs a warm or a cold restart.

WARM RESTART at AC800M only

At a warm restart, variables with the attribute <retain> or <coldretain> are protected by the battery during restart. During the time that the controller is stopped, all output I/Os will keep their last value.

COLD RESTART

At a cold restart, variables with the attribute <coldretain> keep their values, since they are stored on the hard disk. Variables without the attribute <coldretain> lose their values. During the stop time, all output I/Os will keep their last safe state/OSP values.

INIT RESTART


At a Init restart, variables with the attribute <coldretain> or <retain> are returned to the initial value

6.3.3 Download to Flash

For the AC800PEC use the Flash Utility tool to download. But first right click on the controller and “make” the compact flash.


Select “Programs > ABB Industrial IT AC 800 PEC....”

At the very first time when you download to Ram only following windows will pop up:




6.3.4 Download to RAM only

Select “Tools > Download Project and go Online” in the CBM.



If changes have been made to one or several applications in Offline mode, the version analysis detects it. You can then decide how to restart the changed applications.




Independent of how you restart the applications, the changed application parts are downloaded to the controllers. The controller will stop the applications and restart with the new and changed application.

**NOTE! Following download the last message should be:
You are now Online!**


6.3.5 Difference Report

Just before the download to controllers, the system will open a ‘Difference Report’ window, which shows the differences between the applications on disk & applications in the controllers. At this time you may decide to continue or to cancel the download.

The purpose of the difference report is validation of configuration changes.



You may disable the difference report function in project context menu “Settings > Difference Report”.



6.4 Online Functions

6.4.1 General

In Online mode the Control Builder is connected to one or more controllers and offers many diagnostic and inspection features when online to the controller. You can:

- View the executing code dynamically
- Force inputs and outputs at the I/O modules
- Rescale analogue input and output channels
- Change values of variables
- Inspect values of variables

To enter Online mode, go to the tool bar menu of the Control Builder, click on “Tools” and then click on “Online”.

6.4.2 Status of I/O-Signals

Use the status tab of the hardware configuration editor, in online mode, for dynamic online display of I/O channel values and forcing. I/O channel values are updated once every second.

NOTE! The tab is available in Offline mode, but is not editable.

Underflow, overflow, channel and unit errors in online mode are indicated in the Channel value cell by the following icons:

Signal Errors

 underflow	The signal is below the range.
 overflow	The signal is above the range.

Hardware Errors


 Channel error	The channel can have under range, power-up or field power errors.
 Unit error	The unit can be missing or of the wrong type.

6.4.3 Forcing

Forcing of I/O is possible in online mode. Check a check box in the **Forced** column and then type in a value in the **Channel** value column for outputs and in the **Variable** value column for inputs. This value overrides the values in each of those columns.

When a channel is forced all copying between the I/O value and the application value is stopped. The forced value is different for inputs and outputs.

- For inputs the forcing changes the variable value to the application.
- For outputs the forcing changes the physical I/O channel value.




Channel	Channel Value	Forced	Variable Value	Variable
IW1.1.1.1	0.0	<input checked="" type="checkbox"/>	35.0	
IW1.1.1.2	0.0	<input type="checkbox"/>	0.0	
IW1.1.1.3	0.0	<input type="checkbox"/>	0.0	
IW1.1.1.4	0.0	<input type="checkbox"/>	0.0	
IW1.1.1.5	0.0	<input type="checkbox"/>	0.0	
IW1.1.1.6	0.0	<input type="checkbox"/>	0.0	

NOTE! The background of the forced cell changes to yellow to indicate forcing.

Forcing is performed in the hardware configuration editor under the “Status” tab or the POU editor.

Normally only channels with variable connections to application programs can be forced. However, if no variable is connected you have to change the parameter **Copy Unconnected Channels** under the “Settings” tab for the current controller to get a status update.



Parameter	Value	Type	Unit	Min	Max
Copy unconnected channels	Inputs/Outputs	enum			
Latched hardware state	Enabled	enum			
System alarms on hardware unit	Enabled	enum			
Simple events on hardware units	Enabled	enum			
HwStatus update cycle time	1000	dint	ms	500	30000
Clamp Analog out values	true	bool			

6.5 Test Mode & SoftController

6.5.1 Test Mode

Without downloading to a real controller or a SoftController, you may test your application by using the test mode. In CBM, select “Tools > Test mode”.


6.5.2 How to use the SoftController

You may also test your application and even your hardware by downloading to a SoftController running on your PC. It is also possible to use the SoftController for communication purposes, for example, COMLI or MODBUS.


1. Set the controller’s system identity you want to test to your PC’s IP address:2 (such as 172.16.0.1:2).

NOTE! It is also possible to use the loop back adapter address as 127.0.0.1:2.

2. Right click the controller, select “Properties > Simulate Hardware”




3. Start the SoftController by double-click the icon on the desktop or choose the path below:



4. Click "Start".



5. Choose "Download project and Go online".



Exercise 6.1 Downloading

6.1.1 Description

Perform a download of the project to the controller and set various Control Builder M options.

6.1.2 Legend

- > Indicates when you go from one menu to a sub-menu
- Italic* Indicates object and file names
- “ “ Indicates dialog box buttons, tabs, menus etc.
- Bold** Indicates important topics
-  Indicates start/explanation of student activity

6.1.3 Exercise Steps

6.1.3.1 Special Case PEC!

For the AC800PEC use the Flash Utility tool to download. The first step is right click on the controller and “make” the data for the compact flash.



The second step is downloading the file to the PEC



6.1.3.2 Download the Project to the Controller (only RAM)

At the moment, our programming consists only of a single application, *Sxx_ReactorApp*, with some default diagnostic program running under the application (*Program3*). This will be sufficient to use for testing our ability to download.

Three icons are located on Control Builder M's toolbar (and also on the menu) which relate to downloading. Place your cursor over each of them momentarily to get a tooltip text what each of the icons does.

“Test Mode”

Compiles the application and the application executes in the local workstation. The application is NOT downloaded to the physical controller. Test mode is used for checking software before committing it to a controller.



“On-line”

CBM communicates directly with the controller to allow viewing of “live” or “on-line” data. This may only be done if the current application in the controller is the same as that in Control Builder. No download occurs; the Control Builder just connects to the controller and its application.




“Download to Ram only and Go Online”

Causes a new compilation of the project files and downloads the compiled code to the controller. After this is done, Control Builder will be placed into the “online” mode as described above. The menu will provide you with the option to perform a coldstart of the new code and possibly a warmstart. For now, just accept the default start type.





Because this is the first time that the controller has been configured, you need to do a **“Download and Go Online”**.

The Online analysis window will compare the application code and hardware settings in the actual controller and Control Builder.




During the download, you will be presented with the “Difference Report.” To view an item of the report, double click on the item in the left-hand panel. The report will be presented in the right hand pane.






To disable the Difference Report, right click on the project and select **Settings > Difference Report**. Remove the checkbox next to Enable Difference Report and click “OK”.






From the “Tools” menu or using the icon on the toolbar, download to the controller and go online.






Examine any hardware warnings (indicated in yellow on the project tree). First right click on the warning and select “Clear Latched Unit Status”.



If the warnings do not clear, select the module editor and try to determine the cause of the warning. For Analog Inputs, the warnings may be due to a channel **Underflow** which means the input value is less than the configured minimum.





The **DI801** module can be wired such that channel 16 is used to monitor the power for the digital input signals. Because we are not using that function, it is necessary to turn it off in software. Select the editor for the module and change the value of the parameter “Sensor Power Supervision“ to “False”.

NOTE! Control Builder must be offline to make any changes.

Hardware - Controller_1.1.1.2 DI801

Parameter	Value	Type	Unit	Min	Max
Filter time	2	enum	ms		
Sensor power supervision	false	bool			
Activate channel 1	true	bool			
Activate channel 2	true	bool			
Activate channel 3	true	bool			
Activate channel 4	true	bool			
Activate channel 5	true	bool			
Activate channel 6	true	bool			
Activate channel 7	true	bool			
Activate channel 8	true	bool			



Download again to the controller.



Repeat this for the AI810 module and manipulate the potentiometers on the I/O Panel.

Hardware - Controller_1.0.11.1 AI810

Channel	Channel Value	Forced	Variable Value	Variable
IWD.11.1.1	100.0	<input type="checkbox"/>	100.0	
IWD.11.1.2	0.0		0.0	
IWD.11.1.3	54.3	<input type="checkbox"/>	54.3	
IWD.11.1.4	89.2	<input type="checkbox"/>	89.2	
IWD.11.1.5	94.9	<input type="checkbox"/>	94.9	
IWD.11.1.6	84.0	<input type="checkbox"/>	84.0	
IWD.11.1.7	82.9	<input type="checkbox"/>	82.9	
IWD.11.1.8	93.5	<input type="checkbox"/>	93.5	

Exercise 6.2 Writing Simple Code

6.2.1 Description

Write some simple logic code using **Structured Text**. Declare variables and connect them to the input and output channels in the I/O system.

Test the code in online mode and observe the status of simple Boolean variables. Force inputs and outputs using the hardware editor of the relevant I/O module.

6.2.2 Legend

- > Indicates when you go from one menu to a sub-menu
- Italic* Indicates object and file names
- “ “ Indicates dialog box buttons, tabs, menus etc.
- Bold** Indicates important topics
-  Indicates start/explanation of student activity

6.2.3 Exercise Steps


We will be writing some very simple and basic code to run in *Program2* in the *Sxx_ReactorApp* application as an introduction to using the POU editor functions.

NOTE! The editor must be in on off-line mode!

6.2.3.1 Declare Variables



Open *Program2* in application *Sxx_ReactorApp*.





We will need to declare variables to hold the values represented by our I/O points. Declare 4 **BoolIO** variables called *SW1*, *SW2*, *SW3*, and *Lamp1* with no attributes.

Name	Data Type	Attributes	Initial Value	I/O Address	Access Variables
1 SW1	BoolIO				
2 SW2	BoolIO				
3 SW3	BoolIO				
4 Lamp1	BoolIO				+
5					
6					
7					
8					

NOTE! Because these values are directly associated with I/O, no retain-type attributes will be set.

Entries in the “Data Type” and “Attributes” columns may be typed in directly, if known, or a pick-list can be obtained by placing the cursor in the desired cell in the editor and pressing <CTRL-J>.



After making changes check the Program for any errors.

Name	Data Type	Attributes	Initial Value	I/O Address	Access Variables
1 SW1	BoolIO				
2 SW2	BoolIO				
3 SW3	BoolIO				
4 Lamp1	BoolIO				
5					
6					
7					
8					

If Control Builder detects errors, they will be shown in the message (lower) pane in the POU editor. This pane may have to be enabled by selecting “View > Messages Pane” from the menu.

Double-click on an error in the message pane to locate the cursor where the error was detected.

Name	Data Type	Attributes	Initial Value	I/O Address	Access Variables
1 SW1	BoolIO				
2 SW2	BoolIO				
3 SW3	BoolIO				
4 Lamp1	BoolIO				
5					
6					
7					
8					

Cursor
Shown on
Error


:38:
type BoolIO not found within the connected libraries. : Row 2, Column 1, 0 warnings.

Exercise 6.2 - 3

6.2.3.2 Write Logic

We will need to write some logic in the Code Pane in the editor. Programming will actually be covered in several lessons later in the course. We will be inserting some programming code in the **Structured Text** (ST) language – the default language the editor opened up with.

The logic behind our code is very simple. It will evaluate three Digital Inputs and set a Digital Output according to the logic diagram below:



The SW1, SW2, and SW3 variables will be connected to three channels of a digital input module (which are wired to switches) and the Lamp1 variable will be connected to a channel on a digital output module (which is wired to an indicating light).



Type the following line directly in the Code Pane area in the editor. Note that the = sign is actually preceded by a colon and the line must end with a semicolon.


Lamp1.Value := (SW1.Value AND SW2.Value) OR SW3.Value;

Name	Data Type	Attributes	Initial Value	I/O Address	Access Variab
1 SW1	BoolIO				
2 SW2	BoolIO				
3 SW3	BoolIO				
4 Lamp1	BoolIO				
5					
6					
7					
8					

Lamp1.Value := (SW1.Value AND SW2.Value) OR SW3.Value;




Perform a check of your syntax by clicking on the “Check” icon in the tool bar: You




Save and close the POU editor.



Do an off-line test of the logic by taking Control Builder to Test Mode. Click the “Continue” button for the On Line Change analysis dialog and observe that Control Builder enters the “Test” mode by checking the Message Pane in Control Builder.



Take Control Builder to the Off-line mode by pressing the “Stop Test Mode” icon on the toolbar.




6.2.3.3 Connect Variables to I/O Channels

Once variables have been defined (and saved) in a POU editor, they can then become available to connect to the actual hardware channel itself. This is called “I/O Allocation”. I/O allocation is configured in the editor window for each specific I/O module.

Right click on the I/O module to open the Hardware editor and selecting “Editor” or double-click the module object itself. The settings available on each editor will be different depending upon the hardware module type.



Open up the hardware structure in the Control Builder and double click on the DI810



Connect the three switches on the DI810 module to the *SW1*, *SW2*, and *SW3* variables you created in “Program2”. Use the icons in the upper right corner of the editor to choose variables. Save and close the editor when finished.

Channel	Name	Type	Variable	I/O Description
IX0.11.3.1	Input 1	bool	Sxx_ReactorApp.Program2.SW1	
IX0.11.3.2	Input 2	bool	Sxx_ReactorApp.Program2.SW2	
IX0.11.3.3	Input 3	bool	Sxx_ReactorApp.Program2.SW3	
IX0.11.3.4	Input 4	bool		
IX0.11.3.5	Input 5	bool		
IX0.11.3.6	Input 6	bool		
IX0.11.3.7	Input 7	bool		
IX0.11.3.8	Input 8	bool		
IX0.11.3.9	Input 9	bool		

Full Path to Variable



Connect the first channel on the DO810 module to the *Lamp1* variable you created in *Program2*. Check for errors and then save and close the editor when finished.

Channel	Name	Type	Variable	I/O Description
QX0.11.4.1	Output 1	bool	Sxx_ReactorApp.Program2.Lamp1	
QX0.11.4.2	Output 2	bool		
QX0.11.4.3	Output 3	bool		
QX0.11.4.4	Output 4	bool		
QX0.11.4.5	Output 5	bool		

6.2.3.4 Download and Go Online




Download your project to the controller.


6.2.3.5 Viewing Code in Online Mode




Ensure Control Builder is in the Online mode and open the POU editor for *Program 2* and observe your logic in on-line mode. Manipulate the three switches and observe the light on the I/O panel while looking at your logic.



Right click on the variable in the Declaration Pane to get information about the variable and also to open the I/O editor.







6.2.3.6 Change the Online View of Structured Text (ST)


If your code is written in ST, you can alter the views of your logic to either Function Diagram or Ladder (other available programming languages).

Select **Tools > Setup** from the program editor menu bar.



View the logic on-line in the Function Diagram language.





Change the view back to “Text”.

6.2.3.7 Force I/O Signals


I/O may be forced from the “Status” tab in the Hardware editor for the particular I/O module. The editor will have two columns of interest.

- “Channel Value” indicates the actual measured value at the I/O module
- “Variable Value” indicates the value of the variable in the program logic that the I/O channel is connected to


These two values will be equal if the channel is not forced. For input modules, you can change the value of the variable being written to by the I/O module. For output modules, you can force the channel’s output value.



Right-click on the *SW1* variable and select “I/O Editor” to open the hardware editor for the DI810 module.



Ensure the “Status” tab is selected at the bottom of the hardware editor and force one or more variables. Observe the resulting changes in your Program2 editor’s code pane as you force and release forces on variables.



Solution 6.2 Writing Simple Code

6.2.1 Description

Write some simple logic code using **Structured Text**. Declare variables and connect them to the input and output channels in the IO system.

Test the code in online mode and observe the status of simple Boolean variables. Force inputs and outputs using the hardware editor of the relevant IO module.

6.2.2 Legend

- > Indicates when you go from one menu to a sub-menu
- Italic* Indicates object and file names
- “ “ Indicates dialog box buttons, tabs, menus etc.
- Bold** Indicates important topics
-  Indicates start/explanation of student activity

6.2.3 Solution Steps

We will be writing some very simple and basic code to run in *Program2* in the *Sxx_ReactorApp* application as an introduction to using the POU editor functions.


NOTE! The editor must be in on off-line mode!

6.2.3.1 Declare Variables




Open *Program2* in application *Sxx_ReactorApp*.

1. Make sure that Control Builder M is in offline mode
2. Expand the *Applications* object and select *Program2* located under your *Sxx_ReactorApp* object. You can open the POU for this program either by double-clicking *Program2* or right-clicking and selecting “Editor” from the context menu.



3. Locate the available panes, tabs, and menu items to allow you to navigate in the editor window.





Declare 4 **BoolIO** variables called *SW1*, *SW2*, *SW3*, and *LAMP1* with no attributes.


1. Make sure you are selected to the “Variables” tab in the declaration (upper) pane in the POU editor and enter the names of the variable in the “Name” column.

	Name	Data Type	Attributes	Initial Value	I/O Address	Access
1	SW1	BoolIO				
2	SW2	BoolIO				
3	SW3	BoolIO				
4	LAMP1	BoolIO				
5						
6						
7						
8						


2. Place your cursor in the **DataType** column and press <CTRL-J> and select the data type “BoolIO”.

	Name	Data Type	Attributes	Initial Value	I/O Address	Access
1	SW1	BoolIO	retain			
2						
3						
4						
5						
6						
7						
8						

3. Also try selecting the “Insert...” Icon on the upper right corner of the POU editor window.




4. Delete the retain attributes which by default will be added when creating variables. Select the entire “Attributes” column by clicking on the column header and delete all entries by pressing the “delete” key on the keyboard.




	Name	Data Type	Attributes	Initial Value	I/O Address	Access Variab
1	SW1	BoolIO	retain			
2	SW2	BoolIO	retain			
3	SW3	BoolIO	retain			
4	lamp1	BoolIO	retain			
5						

5. Or mark with the mouse and right click, select “Clear”




	Name	Data Type	Attributes	Initial Value	I/O Address	Access Variab
1	SW1	BoolIO	retain			
2	SW2	BoolIO	retain			
3	SW3	BoolIO	retain			
4	lamp1	BoolIO	retain			
5						
6						
7						
8						

6. Check the POU for errors. In the tab “check” the 0 Errors, 0 warnings



	Name	Data Type	Attributes	Initial Value	I/O Address	Access Variab
1	SW1	BoolIO				
2	SW2	BoolIO				
3	SW3	BoolIO				
4	lamp1	BoolIO				
5						
6						
7						
8						

7. Save




	Name	Data Type	Attributes	Initial Value	I/O Address	Access Variab
1	SW1	BoolIO				
2	SW2	BoolIO				
3	SW3	BoolIO				

6.2.3.2 Write Logic



The logic must evaluate three Digital Inputs and set a Digital Output according to the logic diagram below:




1. Type the following line directly in the Code Pane area in the editor.

Lamp1.Value := (SW1.Value AND SW2.Value) OR SW3.Value;


Name	Data Type	Attributes	Initial Value	I/O Address	Access Variab
1 SW1	BoolIO				
2 SW2	BoolIO				
3 SW3	BoolIO				
4 Lamp1	BoolIO				
5					
6					
7					
8					

Lamp1.Value := (SW1.Value AND SW2.Value) OR SW3.Value;


- The already defined variables can be marked from a list using keyboard Ctrl J
The following keyboard code can be used:
Ctrl j, arrow down, select SW1, Enter,
.(dot), arrow down, select Value, Enter.
Arrow down can be replaced by typing the first letter in the item of the list



- Select the keyboard . (dot) behind the SW1 and the Value will be browsed



- Select the 'Check' Icon in the tool bar: You should get 0 Errors and 0 Warnings.




- Save and close the POU editor.


6. Select “Test Mode”.




7. Click the “Continue” button for the On Line Change analysis dialog and observe that Control Builder enters the “Test” mode



8. Check the Message Pane in Control Builder.



9. Take Control Builder to the Off-line mode by pressing the “Stop Test Mode” icon on the toolbar.




6.2.3.3 Connect Variables to IO Channels




Connect the three switches on the DI810 module to the SW1, SW2, and SW3 variable you created in Program2


1. Open up the hardware structure in the Control Builder and double click on the DI810 module in the tree:




2. Connect the three switches on the DI810 module to the *SW1*, *SW2*, and *SW3* variables you created in "Program2". Use the icons in the upper right corner of the editor to choose variables. Open the tree to view the variables, select the +




3. Save and close the editor when finished.



4. Select DO810



5. Connect the first channel on the DO810 module to the *Lamp1* variable you created in *Program2*. Check for errors and then save and close the editor when finished.




6. Download and Go Online. Select “Continue”

6.2.3.4 View Code in Online Mode




Check Control Builder is in the On-Line mode and open the POU editor for Program 2 and observe the logic is in on-line mode.

1. Manipulate the three switches and observe the light on the IO panel while looking at your logic.



2. Right click on the variable in the Declaration Pane to get information about the variable and also to open the I/O editor. on


3. For information right click at a variable



4. Read the information regarding to I/O address and Application



5. Select the hardware tab “Status” to view the connections




6.2.3.5 Change the Online View of Structured Text (ST)


1. Select Tools > Setup from the program editor menu bar.




2. Select radio button for Function Diagram, Select "OK"




3. View the logic on-line in the Function Diagram language.




4. View the logic on-line in the Ladder language.



5. Change a switch at the panel.




6. Change the view back to Text.





Forcing IO

1. Open the hardware editor screen for the DI810 module by right-clicking the SW1 variable in the program editor and selecting “I/O Editor” from the context menu.



2. Select the “Status”, and force one or more variables. Observe the resulting changes in your Program2 editor’s code pane as you force and release forces on variables.

